

Mulch Block Mulch Collar - Easy Installation



Tree growing in bare ground before mulch



Mulch collar placed around base of tree at desired size. A nail stakes tape in place.



Top view of mulch placed up to collar. Base of tree is clear of mulch.



Side view of mulch placed up to collar.

Mulch Block Mulch Collars come in ten foot lengths, 100 foot lengths, and custom lengths. A 10-foot section is expandable and re-usable from planting to about 18-inch trunk flare diameter. The heights are available in custom sizes. The standard height is 4 inches.

Simple maintenance is required over time to clear water holding debris from the space between the collar and the tree, and expand the collar as the tree grows larger.

Stop burying trees and control the height of mulch volcanoes with Root Block Root Collars.

The only tools and materials needed are sturdy tape (black is preferred), a sharp knife, and nails (to stake the collar in place).